

# Playstation 4 Game Controller Security Bracket and Tether Installation Instructions

Thank you for purchasing a game controller security bracket from secure entertainment. We have spent years developing this product and hope that it will help secure the controllers in your public gaming space. Please contact us at info@secure-entertainment.com if you have any questions.

US Patent 11,103,796

#### Parts Included:

- Bracket
- USB and Security Cable Tether
- Security screw (for securing bracket around the controller)
- Security screw (for attaching security cable to a secure surface)
- Security screwdriver bit
- Plastic shim for USB Cable

#### Not Included:

- Screwdriver (any screwdriver with interchangeable bits will work)
- Drill bit and drill

### **Safety Precautions**

- Be sure to secure the security cable to a secure surface that will withstand the tension of the cables being pulled.
- Use caution and be aware of trip hazards created by cables
- Contains small parts (screws and screwdriver bits). Keep out of reach of small children
- If using with a Secure Entertainment Security case, Do not attach security cable directly to the case.

## PLAYSTATION 4 BRACKET



STEP I



Grab bracket part shown above and feed USB plug that connects to the controller through opening that lines up with the USB slot on the controller. Plug in the USB cable to the controller. Insert the barrel end of the security cable into the rectangular opening on the bottom of the bracket.

STEP 2



Align the bracket and the cable so it surrounds the top of the controller. Make sure to insert the USB cable into the round slot located at the top of the bracket. Clip on the plastic shim that was included in the packaging around the USB cable head.

STEP 3



Slide the bracket over the top of the controller and align the plastic shim as shown.

## STEP 4



Next, take the bottom part of the bracket and place it onto the controller from the bottom making sure to align the security cable into the slot in the bracket.

STEP 5



From the top of the bracket. Insert the security screw and tighten using the screwdriver bit provided

### SECURING THE SECURITY CABLE

Please refer to the safety precautions on the first page before attaching the security cable to a secure surface

**Option 1: Security Screw Installation** 



Pre-drill the hole that you will be using to attach the security cable using the provided security screw and washer. Insert the security screw into the hole of the washer and place this on top of the eyelet on the security cable and use the provided screwdriver bit to secure the cable to the surface.

Plug in the usb cable into the game console and your gamers are ready to play!



Option 2: Loop Through

Optionally, you can wrap the security cable around a secure piece of furniture. Simply wrap the cable around the location you want to install and pass through the USB and the other end of the security cable through the loop.

Plug in the usb cable to the game console and your gamers are ready to play!